


## Crankcase Breather

1. Remove the drain plug (1) from the tube, and drain deposits.
2. Reinstall the drain plug.

**NOTE:** Service more frequently when ridden in rain, at full throttle or after the motorcycle is washed or overturned. Service if the deposit level can be seen in the transparent section of the drain tube.



---

## Reniflard

1. Enlever le bouchon de vidange (1) du tuyau et vidanger les dépôts.
2. Remettre en place le bouchon de vidange.

**NOTE:** Effectuer plus souvent cette opération si l'on conduit sous la pluie, à pleins gaz ou si la moto a été lavée ou basculée. Vidanger également si l'on peut voir le niveau de dépôt dans la partie transparente du tuyau de vidange.