

# Instruments

(VFR1200X)

**Tachometer red zone**  
(excessive engine rpm range)



**Tachometer**

## NOTICE

Do not operate the engine in the tachometer red zone. Excessive engine speed can adversely affect engine life.

**TOTAL/TRIP button**

**FCD button**

**TOTAL/TRIP button & FCD button**

(E type only)

Press and hold both buttons to change the speed, mileage and fuel mileage units ("km/h" & "km" & "km/L" or "mph" & "mile" & "mile/L") for the speedometer, odometer, and tripmeter.

Press **FCD** button to select either "km/h" & "km" & "km/L" or "mph" & "mile" & "mile/L", then press **TOTAL/TRIP** button to set.