

## **TIRES: TUBELESS**

This motorcycle is equipped with tubeless tires, valves, and wheel rims. Use only tires marked "TUBELESS TIRE APPLICABLE".

Proper air pressure will provide maximum stability, riding comfort and tire life.

Check tire pressure frequently and adjust if necessary.

### **NOTE:**

- **Tire pressure should be checked when the tires are " cold", before you ride.**
- **Tubeless tires have some degree of selfsealing ability if they are punctured, and leakage is often very slow. Inspect very closely for punctures, especially if the tire is not fully inflated.**

---

## **PNEUS: TUBELESS**

Cette moto est équipée de pneus tubeless, de valves et de jantes correspondant à ceux-ci. N'utiliser que des pneus marqués "TUBELESS TIRE APPLICABLE" (utilisable pour pneu tubeless).

Une pression de gonflage appropriée assurera la stabilité, le confort de conduite et la longévité des pneus. Dès lors, vérifier-la régulièrement et régler-la cas échéant.

### **NOTE:**

- **La vérification de la pression de gonflage doit être faite "à froid", c'est-à-dire avant de rouler.**
- **Dans une certaine mesure, les pneus tubeless restent étanches, même s'ils sont crevés et le dégonflage s'effectue souvent petit à petit. Examiner attentivement la présence éventuelle de fuites, surtout si les pneus ne sont pas très gonflés.**