MAINTENANCE

Brake Pad Wear

Page

79

51	MAINTENANCE	80 Battery
52	Maintenance Schedule	83 Fuse Replacement
54	Tool Kit	85 Stoplight Switch Adjustment
55	Serial Numbers	
56	Colour Label	86 CLEANING
56	Maintenance Precautions	
57	Engine Oil	87 STORAGE GUIDE
61	Spark Plugs	87 Storage
63	Throttle Operation	88 Removal from Storage
64	Idle Speed	
65	Drive Chain	89 NOISE EMISSION (AUSTRALIA ONLY)
70	Front and Rear Suspension	
71	Side Stand	90 SPECIFICATIONS
72	Wheel Removal	

Page