

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			x 1,000 km	1	6	12	18	24	30	36	
			x 1,000 mi	0.6	4	8	12	16	20	24	
			MONTH		6	12	18	24	30	36	
	DRIVE CHAIN		EVERY 1,000 km (600 mi) I, L								71-74
	DRIVE CHAIN SLIDER				I		I		I	75	
	BRAKE FLUID	(NOTE 3)		I	I	R	I	I	R	19-22	
	BRAKE PAD WEAR			I	I	I	I	I	I	84	
	BRAKE SYSTEM		I		I		I		I	19-22	
*	BRAKE LIGHT SWITCH				I		I		I	95	
*	HEADLIGHT AIM				I		I		I	—	
	CLUTCH SYSTEM				I		I		I	23-24	
	SIDE STAND				I		I		I	—	
	CLUTCH FLUID	(NOTE 3)		I	I	R	I	I	R	—	
*	SUSPENSION				I		I		I	—	
*	NUTS, BOLTS, FASTENERS		I		I		I		I	—	
**	WHEELS/TYRES				I		I		I	—	
**	STEERING HEAD BEARINGS		I		I		I		I	—	