

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	× 1,000 km ↓ MONTH	ODOMETER READING [NOTE (1)]								REFER TO PAGE
				1	6	12	18	24	30	36	24	
				0.6	4	8	12	16	20	24	36	
* FUEL LINE						I		I		I	—	
* THROTTLE OPERATION						I		I		I	105	
AIR CLEANER		NOTE (2)					R			R	94	
SPARK PLUGS				EVERY 24,000 km (16,000 mi) I, EVERY 48,000 km (32,000 mi) R							100-104	
* VALVE CLEARANCE								I			—	
ENGINE OIL				R		R		R		R	95-99	
ENGINE OIL FILTER				R		R		R		R	97-99	
* ENGINE IDLE SPEED				I	I	I	I	I	I	I	106	
RADIATOR COOLANT		NOTE (3)				I		I		R	36-37	
* COOLING SYSTEM						I		I		I	—	
* SECONDARY AIR SUPPLY SYSTEM						I		I		I	—	