

ITEM	FREQUENCY	WHICHEVER →	ODOMETER READING [NOTE(1)]								REFER TO PAGE	
			COMES FIRST ↓	x 1,000 km	1	6	12	18	24	30		36
				x 1,000 mi	0.6	4	8	12	16	20		24
			NOTE	MONTH		6	12	18	24	30		36
	DRIVE CHAIN			I, L, EVERY 1,000 km (600 mi)								83-87
	DRIVE CHAIN SLIDER				I			I		I	88	
	BRAKE FLUID	(NOTE 3)			I	I	R	I	I	R	23-26	
	BRAKE PAD WEAR				I	I	I	I	I	I	99	
	BRAKE SYSTEM			I		I		I		I	23-26, 100	
*	BRAKE LIGHT SWITCH					I		I		I	106	
*	HEADLIGHT AIM					I		I		I	-	
	CLUTCH SYSTEM					I		I		I	27	
	CLUTCH FLUID	(NOTE 3)			I	I	R	I	I	R	27	
	SIDE STAND					I		I		I	100	
*	SUSPENSION					I		I		I	99	
*	NUTS, BOLTS, FASTENERS			I		I		I		I	-	
**	WHEELS/TYRES					I		I		I	-	
**	STEERING HEAD BEARINGS			I		I		I		I	-	