



**Odometer [TOTAL] & Tripmeter [TRIP A/B]
& Mileage countdown** ➡ P.23

Fuel gauge

Remaining fuel when only 1st (E) segment starts flashing: approximately 3.5 litres (0.92 US gal, 0.77 Imp gal)



If the fuel gauge indicators repeat flashing or turned off: ➡ P.103

Handle grip heater status icon

The handle grip heater status icon will appear while the handle grip heater is on.

**Clock (12-hour display)/Trip time/
Handle grip heater level** ➡ P.29