

Average speed

Displays the average speed since the selected tripmeter was reset.

The average speed will be calculated based on value displayed on the tripmeter (A or B) selected. Also, the average speed for tripmeter A will be displayed when the odometer or the mileage countdown is selected.

- Initial display: “---” is displayed
When “---” is displayed while riding, go to your dealer for service.

To reset the average speed:  P.28