


Instruments *(Continued)*

Display Setting

Following items to change sequentially.

- Clock setting
- Backlight brightness adjustment
- HISS indicator setting
- Changing the speed and mileage unit
- Changing the fuel mileage meter unit
- Setting the mileage countdown



➡ Press and hold **SEL** button and **SET** button

⇩ Press **SET** button