

If the ignition switch is turned off, the button is not pressed for about 30 seconds, or the handle grip heater level is changed, the control is automatically switched from the setting mode to the ordinary display. If the button is not pressed for about 30 seconds or the handle grip heater level is changed, items in the process of being set will be discarded and only items where settings have been finalised will be applied. Only if the ignition switch is turned off will items in the process of being set and those that are finalised be applied.

### 1 Clock setting:

- 1 Turn the ignition switch ON.
- 2 Press and hold **SEL** button and **SET** button, the hour digits start flashing.
- 3 Press **SEL** button until the desired hour is displayed.  
▶ Press and hold **SEL** button to advance the hour fast.



- 4 Press **SET** button. The minute digits start flashing.

