

HISS Indicator ..... 30, 37, 98  
Horn Button ..... 39

**I**

**Ignition Cut-off System**

Banking Sensor ..... 120  
Side Stand ..... 84  
Ignition key ..... 117  
Ignition Switch ..... 39, 45, 118  
Image Labels ..... 6  
Indicators ..... 36  
Instruments ..... 20

**L**

Labels ..... 6  
Load Limits ..... 17  
Loading Guidelines ..... 17  
Low fuel Indicator ..... 36  
Low Oil Pressure Indicator ..... 36, 100

**M**

**Maintenance**

Fundamentals ..... 56

Importance ..... 52  
Safety ..... 52  
Schedule ..... 53  
Maximum Weight Limit ..... 17  
Modifications ..... 16

**N**

Neutral Indicator ..... 36

**O**

Odometer ..... 23, 118  
Oil  
Engine ..... 60, 75  
Overheating ..... 99

**P**

Parking ..... 14  
Parts Location ..... 18  
Passing light control switch ..... 38  
Petrol ..... 47  
PGM-FI (Programmed Fuel Injection)  
Malfunction Indicator Lamp (MIL) .... 36, 100  
Protective Apparel ..... 11