


Odometer/Tripmeter Display

The display (1) has two functions, odometer and tripmeter.

The tripmeter has two sub modes, "TRIP 1" and "TRIP 2".


Push the button (2) to select the "ODO", "TRIP 1" or "TRIP 2" mode.

To reset the tripmeter, push and hold the button with the display in the "TRIP 1" or "TRIP 2" mode.




- (1) Odometer/Tripmeter display
- (2) Odometer/Tripmeter select and reset button


Odometer



Tripmeter 1



Tripmeter 2



Tripmeter reset

