

MAINTENANCE

page

62 MAINTENANCE

- 62 THE IMPORTANCE OF MAINTENANCE
- 63 MAINTENANCE SAFETY
- 64 SAFETY PRECAUTIONS
- 65 MAINTENANCE SCHEDULE
- 68 TOOL KIT
- 69 SERIAL NUMBERS
- 70 COLOUR LABEL
- 71 ENGINE OIL
- 75 CRANKCASE BREATHER
- 76 SPARK PLUGS
- 78 FINAL DRIVE OIL
- 79 THROTTLE OPERATION
- 80 IDLE SPEED
- 81 COOLANT
- 82 AIR CLEANER
- 83 FRONT AND REAR SUSPENSION INSPECTION
- 84 SIDE STAND
- 85 WHEEL REMOVAL
- 91 BRAKE PAD WEAR
- 92 BRAKE SHOE WEAR

page

- 93 BATTERY
- 96 FUSE REPLACEMENT
- 99 STOPLIGHT SWITCH ADJUSTMENT
- 100 BULB REPLACEMENT
- 105 CLEANING**
- 108 STORAGE GUIDE**
 - 108 STORAGE
 - 110 REMOVAL FROM STORAGE
- 111 SPECIFICATIONS**
- 115 CATALYTIC CONVERTER**
- 116 NOISE CONTROL SYSTEM (AUSTRALIA ONLY)**