

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		NOTE	MONTH								
* FUEL LINE					I		I		I		—
* THROTTLE OPERATION					I		I		I		92
* CHOKE OPERATION					I		I		I		—
* AIR CLEANER		NOTE (2)					I		I		—
CRANKCASE BREATHER		NOTE (3)			C	C	C	C	C	C	87
SPARK PLUGS					EVERY 24,000km (16,000mi) I, EVERY 48,000km (32,000mi) R						88
* VALVE CLEARANCE								I			—
ENGINE OIL				R		R		R		R	81
ENGINE OIL FILTER				R		R		R		R	84
* ENGINE IDLE SPEED				I	I	I	I	I	I	I	93
RADIATOR COOLANT		NOTE (4)				I		I		R	32
* COOLING SYSTEM						I		I		I	—
* SECONDARY AIR SUPPLY SYSTEM		NOTE (5)				I		I		I	—