

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
DRIVE CHAIN			I, L EVERY 1,000km (600mi)								95
DRIVE CHAIN SLIDER					I			I		I	101
BRAKE FLUID		NOTE (4)			I	I	R	I	I	R	27
BRAKE PAD WEAR					I	I	I	I	I	I	112
BRAKE SYSTEM				I		I		I		I	27
* BRAKE LIGHT SWITCH						I		I		I	118
* HEADLIGHT AIM						I		I		I	59
CLUTCH SYSTEM						I		I		I	30
CLUTCH FLUID		NOTE (4)			I	I	R	I	I	R	30
SIDE STAND						I		I		I	103
* SUSPENSION						I		I		I	--
* NUTS, BOLTS, FASTENERS				I		I		I		I	--
** WHEELS/TYRES						I		I		I	--
** STEERING HEAD BEARINGS				I		I		I		I	--