



## Gauges, Indicators & Displays


### Changing the Speed Unit

(USA Only)

The speedometer displays both “mph” and “km/h.”

Push and hold the multi-function select and reset button (4) to select “mph” or “km/h.”

This function only operates while the display is in the “ODO” mode (page 28).



(4) multi-function select and reset button

