



## Coolant

### **WARNING**

Removing the radiator cap while the engine is hot can cause the coolant to spray out, seriously scalding you.

Always let the engine and radiator cool down before removing the radiator cap.

### **NOTICE**

*Improper disposal of drained fluids is harmful to the environment.*

To properly dispose of drained coolant, refer to *You & the Environment*, page 164 .

