



## **If Your Engine Quits or Won't Start**

<b>SYMPTOM: Starter motor doesn't operate.</b>	
<b>POSSIBLE CAUSE</b>	<b>WHAT TO DO</b>
ignition switch OFF	Turn the ignition switch ON.
engine stop switch OFF	Turn the engine stop switch to RUN.
transmission not in neutral	Shift into neutral.
side stand down (when transmission not in neutral)	Put the transmission in neutral or raise the side stand and pull the clutch lever in.
blown fuse	Replace with a new fuse of the same rating (page 187).
battery lead loose	Tighten the battery lead.
dead battery	Charge the battery (page 150). If charging doesn't help, see your Honda dealer.
faulty starter motor	If all possible causes are negative, the starter motor may be faulty. See your Honda dealer.



### **168 Taking Care of the Unexpected**

