

---

### Turn Signal Indicator

Flashes when the turn signal is ON.

### High Beam Pilot Lamp


Lights if the high beam is selected.

### Neutral Indicator

Lights if the engine is in neutral gear and the main switch key is at ON position.

Turn Signal  
Indicator

High Beam  
Pilot Lamp



Neutral Indicator