

Changing Gear

The VTR 250 has a five speed return gear change:

- Release the throttle and fully squeeze the clutch lever before selecting / changing gear.
- Operate the gear shift pedal gently but firmly using your toe (excessive force may damage the gear change system). You should be able to feel the gear changer click solidly into place.

