

< Brake pads inspection >

Honda recommends that brake pads be inspected regularly, between services.

Inspect the brake pads from underneath the calipers.

If the wear limit line is worn through to the side of the brake disc, replace the pads on both sides.

Contact an Authorized Honda Dealer for brake pad replacement.

Always replace brake pads as a set - failure to do so may cause uneven braking or instability.

