

STARTING THE ENGINE

⚠ WARNING

- * **Never run the engine in an enclosed area.**
The exhaust contains poisonous carbon monoxide gas that can cause loss of consciousness and lead to death.
- * **Attempting to start the engine with the transmission in gear and the clutch engaged may result in injury or damage.**

NOTE:

- * This motorcycle can be kickstarted with the transmission in gear by disengaging the clutch before operating the kickstarter.
- * Since the engine decompression system is interlocked with the kickstarter, a quick, vigorous kick from the top of the stroke is most effective.

Preparation

1. Make sure the transmission is in neutral and the fuel cock is ON.
2. Insert the key in the ignition switch and turn to ON. The neutral indicator (green) should go on.
3. Make sure the engine stop switch is in RUN.