


5. Check the chain slider for wear. When the thickness of the chain slider reaches the limit, the chain slider must be replaced. See your authorized Honda dealer. Chain slider thickness limit:
3.0 mm (0.12 in)



- (2) Chain slider
(3) Thickness