

CONTENTS //

SERIAL NUMBER LOCATION	7
CONTROL LOCATION	8
OPERATING INSTRUCTIONS	11
Main Switch	11
Steering Lock	12
Seat Lock and Helmet Holder	12
Speedometer/Tachometer	13
Turn Signal Switch.....	15
Horn Button	15
Ignition Switch	15
Headlight Switch.....	16
Document Compartment	16
FUEL AND OIL	17
Fuel Tank	17
Fuel Filler Cap.....	17
Fuel Valve.....	18
Engine Oil Recommendation	19
Viscosity	19