

CONTENTS

| | |
|--|-----|
| MOTORCYCLE SAFETY | 8 |
| PROTECTIVE APPAREL | 12 |
| LOADING AND ACCESSORIES | 14 |
| OFF-ROAD SAFETY | 20 |
| EQUIPMENT AND CONTROLS | 24 |
| FUEL AND OIL | 44 |
| PRE-RIDING INSPECTION | 50 |
| STARTING THE ENGINE | 54 |
| BREAK-IN PROCEDURE | 58 |
| RIDING THE MOTORCYCLE | 60 |
| MANINTENANCE | 62 |
| Engine oil | 62 |
| Spark plug | 66 |
| Valve tappet clearance | 68 |
| Starter decompressor | 72 |
| Cam chain adjustment | 74 |
| Air cleaner servicing | 76 |
| Throttle operation | 78 |
| Carburetor adjustment | 80 |
| Clutch adjustment | 84 |
| Drive chain | 86 |
| Brakes | 92 |
| Stoplight switch adjustment | 98 |
| Front and rear suspension inspection | 100 |
| Front wheel removal | 102 |
| Rear wheel removal | 106 |
| Battery care | 110 |
| Fuse replacement | 112 |
| Tire servicing | 114 |
| Tool kit | 116 |
| MAINTENANCE SCHEDULE | |
| SPECIFICATIONS | |
| WIRING DIAGRAM | |