

Maintenance Schedule

Items	Frequency	Whichever Comes First ⇒	Regular Maint. Interval					Refer to page:
			Initial Maint.	600	1,200	1,800	2,400	
			mi	100	2,000	3,000	4,000	
			km	150	1,000	2,000	4,000	
Note	Month	1	6	12	18	24		
EMISSION RELATED ITEMS	*	Fuel Line			I		I	—
	**	Fuel Strainer Screen			C		C	—
	*	Throttle Operation			I		I	68
		Air Cleaner	Note 1		C	C	C	65
		Spark Plug			I	I	I	75
	*	Valve Clearance			I	I	I	—
		Engine Oil			R	R	R	59
	**	Engine Oil Strainer Screen			C		C	—
	*	Cam Chain Tension			A	A	A	—
	**	Engine Idle Speed			I	I	I	74

* Should be serviced by your Honda dealer, unless the owner has the proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual (page 148).

** In the interest of safety, we recommend these items be serviced only by your Honda dealer.