

Ref. No.	Description	Function
1	Speedometer	Shows riding speed.
2	Tripmeter	Shows mileage per trip or section of route.
3	High beam indicator light	Lights when headlight is on high beam.
4	Odometer	Shows accumulated mileage.
5	Tripmeter reset knob	To zero (0) the tripmeter, pull the knob to OFF. Push knob to ON to begin counting.