

**CAUTION:**

- \* **To fill the oil tank up to the upper level, oil should be added in two steps.**
5. With the motorcycle upright on firm level ground.
  6. Fill the oil tank with the specified oil (See page 62 ) up to the upper level mark and install the oil filler cap/dipstick.
  7. Start the engine and let it idle for 5 minutes. During idling, support the motorcycle in an upright position on a firm, level surface to assure an accurate oil level reading. Stop the engine.
  8. Immediately remove the oil filler cap/dipstick and add the specified oil up to the upper level mark.
  9. Reinstall the oil filler cap/dipstick. Check for oil leaks.

**CAUTION:**

- \* **Running the engine with insufficient oil can cause serious engine damage.**
- \* **Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil.**

**NOTE:**

- \* Please dispose of used engine oil in a manner that is compatible with the environment. We suggest you take it in a sealed container to your local recycling center or service station for reclamation. Do not throw it in the rubbish or pour it on the ground or down a drain.