Maintenance Schedule

Frequency			Whichever Comes First		Initial Maint.					Refer	
	Trequency		dency	⇒	mi	100	600	1,200	1,800	2,400	to
l Ite	ems				km	150	1,000	2,000	3,000	4,000	page:
***	***			Note	Month	1	6	12	18	24	
EMISSION RELATED ITEMS	*	Fuel Line						I		I	
	*	Throttle Operation						I		I	69
		Air Cleaner		Note 1			C	C	C	C	66
		Spark Plug					I	I	I	I	78
	*	Valve Clearance				I	I	I	I	I	74
		Engine Oil				R	R	R	R	R	60
	* *	Engine Oil Strainer Screen						C		C	
	* *	Engine Oil Centrifugal Filter						C		C	
	* *	Engine Idle Speed				I	l	I	I	I	77

^{*} Should be serviced by your Honda dealer, unless the owner has the proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual (page 146).

^{**} In the interest of safety, we recommend these items be serviced only by your Honda dealer.