

Safety Labels

This page shows the locations of safety labels on your motorcycle. Some labels warn you of potential hazards that could cause serious injury. Others provide important safety information. Read these labels carefully and don't remove them.

If a label comes off or becomes hard to read, contact your Honda dealer for a replacement.

For your protection, always wear your helmet while riding. Operator only. No passengers. Read the owner's manual carefully.

TIRE INFORMATION

COLD TIRE PRESSURES :	FRONT 100kPa	1.00kgf/cm ²	15psi.
	REAR 100kPa	1.00kgf/cm ²	15psi.
MAXIMUM WEIGHT CAPACITY :	60 kg (132 lbs.)		
TIRE SIZE :	FRONT 2.50-14 4PR	REAR 3.00-12 4PR	

OFF ROAD USE ONLY

THIS VEHICLE IS DESIGNED AND MANUFACTURED FOR OFF ROAD USE ONLY. IT DOES NOT CONFORM TO FEDERAL MOTOR VEHICLE SAFETY STANDARDS AND OPERATION ON PUBLIC STREETS, ROADS, OR HIGHWAYS IS ILLEGAL.

