

How to read and use the instrument panel

Gauges

Speedometer

This measures speed while traveling. Travel safely and keep to the regulation speed limit. The top speed range designed for each gear is also shown on the display. Pushing the engine beyond the limits stated will have an adverse affect on the engine.

Odometer

This measures the total distance travelled and displays it in km units. Black figures on a white background are displayed in 100 m units.

