

### **Speed warning light**

This light will start to flash when the motorcycle is traveling over 30km/hr.

### **Neutral light**

This light will show when the main switch is in the "ON" position and the transmission is in neutral.

Neutral display light      Speed warning light

