


# Switches



## Idling stop switch

- **IDLING STOP** : The Idling Stop system is on.
- **IDLING** : The Idling Stop system is off.

## Idling Stop system: P.47

## Hazard switch

The hazard signal is on. Switchable when the ignition switch is on.

## Start button

## Headlight dimmer switch

-  : High beam
-  : Low beam