

Replacing the Honda SMART Key Battery

If the Honda SMART Key indicator flashes 5 times when the ignition switch is turned **I** (On), or the operating range becomes unstable, replace the battery as soon as possible.

We recommend to see your dealer for this service.

Battery type: CR2032

1. Remove the upper case by inserting a coin or a flat head screwdriver covered with a protective cloth into the slit.
 - ▲ Wrap a coin or a screwdriver with a protective cloth to prevent scratching the Honda SMART Key.
 - ▲ Do not touch the circuit or terminal. This may cause problems.
 - ▲ Be careful to avoid scratching the waterproof covering or allowing dust to enter.
 - ▲ Do not forcibly dismantle the Honda SMART Key body.