

Honda SMART Key Indicator

■ When the Honda SMART Key indicator flashes 5 times

Replacing the Honda SMART Key Battery P. 91

■ When the Honda SMART Key indicator is flashing while the ignition switch is in the **I** (On) position

The Honda SMART Key indicator flashes when communication between your vehicle and Honda SMART Key stops after turning the ignition switch to the **I** (On) position. It is probably caused by the following:

- Strong radio waves or noise are affecting the system

- Unable to authenticate between Honda SMART Key and vehicle when pressing the start button or ignition switch.
- You lose the Honda SMART Key while riding

However, this does not affect the operation of your vehicle until the ignition switch is locked.

If you turn the ignition switch to the SEAT FUEL, **O** (Off) or **L** (Lock) position while the Honda SMART Key indicator is flashing, the ignition switch ring and Honda SMART Key indicator will rapidly flash, and the buzzer will ring for about 20 seconds, automatically go off, and then the ignition switch will lock.

- Turn signals blink at the beginning and end of this function.