





FRONT WHEEL/FRONT FORK/STEERING

Install the headlight using the two screws.
Install the bulb in the headlight with the lugs of the bulb aligned with the cutouts of the headlight.



Place the headlight bulb socket spring over the bulb.
Install the bulb socket on the bulb by aligning the grooves with the lugs of the bulb and turning it in the direction of the arrow while pressing it down by hand.



Install the socket holder on the socket with the arrow mark facing up.

