



BRAKE PADS/ DISC

BRAKE PAD REPLACEMENT

NOTE

Do not disconnect the brake hose when replacing the brake pads.

Loosen the lock nut and remove the parking brake adjusting bolt.

Remove the parking brake arm and cable from the rear caliper.

Remove the two caliper bolts and remove the caliper from the swingarm.

Straighten the tabs of the lock plate.

