

After '86:

ITEM		FREQUENCY	EVERY	INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
*	FUEL LINE		YEAR; I			3-7
*	FUEL STRAINER SCREEN		YEAR; C			3-7
*	THROTTLE OPERATION			I	I	3-8
*	CARBURETOR CHOKE				I	4-5
	AIR CLEANER		NOTE 2		C	3-4
	AIR CLEANER CASE DRAIN TUBE		NOTE 3		I	3-5
	SPARK PLUG				I	3-5
*	VALVE CLEARANCE			I	I	3-5
	ENGINE OIL			R	R	2-2
	ENGINE OIL FILTER			R	R	2-2
*	CARBURETOR IDLE SPEED			I	I	3-5
	FINAL DRIVE OIL		YEAR; I 2 YEARS; R			2-3
*	BRAKE SHOE WEAR		YEAR; I NOTE 3			3-9
	BRAKE SYSTEM			I	I	3-9
*	REVERSE LOCK SYSTEM			I	I	3-12
	SKID PLATE, GUARD PLATE				I	3-14
*	CLUTCH SYSTEM			I	I	3-11
*	SUSPENSION				I	11-20, 12-13
*	SPARK ARRESTER (U.S.A. only)		NOTE 1		C	3-11
*	NUT, BOLT, FASTENER			I	I	3-12
**	TIRES			I	I	3-13
**	STEERING HEAD BEARING		YEAR; I			3-13

\* Should be serviced by an authorized Honda dealer, unless the owner has proper tools and is mechanically qualified.

\*\* In the interest of safety, we recommend these items be serviced an authorized Honda dealer.

NOTE: 1. U.S.A. only.

2. Service more frequently when riding in dusty areas, sand or snow.

3. Service more frequently after riding in very wet or muddy conditions.