

MAINTENANCE

MAINTENANCE SCHEDULES

'85:

- The maintenance intervals shown in the following schedule are based upon average riding conditions. ATC's subjected to severe use, or ridden in unusually dusty areas, require more frequent servicing.

Perform the Pre-ride Inspection in the Owner's Manual at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean R: Replace L: Lubricate	EVERY	INITIAL	REGULAR	Refer to page
		SERVICE PERIOD (First week of operation)	SERVICE PERIOD (Every 30 operating days)	
ENGINE OIL		R	R	2-2
ENGINE OIL FILTER		R	R	2-2
AIR CLEANER	NOTE 1		C	3-4
SPARK PLUG			I	3-5
* VALVE CLEARANCE		I	I	3-5
* CARBURETOR-IDLE SPEED		I	I	3-6
FUEL LINE	YEAR I			3-7
* FUEL STRAINER SCREEN	YEAR C			3-7
* THROTTLE OPERATION		I	I	3-7
DRIVE CHAIN	NOTE 1	I,L	I,L	3-9
DRIVE CHAIN SLIDER			I	3-11
* SUSPENSION			I,L	3-11
* BRAKE PADS	YEAR I			3-12
BRAKE FLUID	2 YEARS R		I	3-13
BRAKE SYSTEM		I	I	3-13
* CLUTCH		I	I	3-16
* SPARK ARRESTER	NOTE 3		C	3-16
NUTS, BOLTS, FASTENERS		I	I	3-17
** WHEELS/TIRES		I	I	3-17
** STEERING HEAD BEARINGS	YEAR I			3-18
** REAR BRAKE PIVOTS	YEAR I			3-14

* Should be serviced by an authorized Honda dealer, unless the owner has proper tools and service data and is mechanically qualified.

** In the interest of safety, we recommend these items be serviced ONLY by an authorized HONDA dealer.

- NOTES: 1. Service more frequently when riding in dusty areas.
2. Service more frequently after riding in very wet or muddy conditions.
3. U.S.A. only