

ASSEMBLY

Coat all parts with oil.

Assemble the transmission shafts and gears, noting the locations of the thrust washers and snap rings.

Make sure that the snap rings are seated properly.

Align the C4 gear lock washer tabs with the grooves in the spline washer as shown.

