
Switches



Engine stop switch

 Should normally remain in the (Run) position.

 In an emergency, switch to the (Off) position (the starter motor will not operate) to stop the engine.

Hazard switch

Switchable when the ignition switch is on. Can be turned to off regardless of the ignition switch position.

► The signals continue flashing with the ignition switch in OFF or LOCK after the hazard switch is on.

③ Start button

Headlight turns off when operating the starter motor.