
## **Gauges, Indicators & Displays**

- 6. To set the minute, push the RESET button until the desired minute is displayed. The minute display will return to "00" when "60" is reached without affecting the hour display.
  - The time advances by one minute, each time the button is pushed.
  - Quick setting—push and hold the RESET button until the desired minute appears.



- 7. To end the adjustment and proceed to change the speed and mileage unit (page 34), push the SET button.
  - To end the adjustment, push and hold both the SET and RESET button for more than 2 seconds or turn the ignition switch OFF.

The display will stop flashing automatically and the adjustment will be cancelled if the button is not pressed for about 30 seconds.