

Fuel

2. Open the fuel fill cap.
3. Add fuel until the level reaches the level plate (3). Avoid overfilling the tank. There should be no fuel above the level plate.
4. After refueling, push the fuel fill cap closed until it snaps and locks.
5. Remove the ignition key from the fuel fill cap.

WARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.