

Front Wheel

Removal

1. Park on a firm, level surface.
2. Cover both sides of the front wheel and brake caliper with protective tape or cloth.
3. **(CB1000R ABS)**

Remove the wheel speed sensor by removing the bolts.

