

The average fuel mileage and fuel consumption will be based on tripmeter A.

- **Current fuel mileage:**
Current instant fuel mileage. If your speed is less than 5 mph (7 km/h), " --.- " is displayed.
When " --.- " is displayed at speeds above 5 mph (7 km/h), go to your dealer for service.
- **Average fuel mileage:**
Average fuel mileage since tripmeter A was reset. When " --.- " is displayed, see your dealer for service.
- **Fuel consumption:**
Total fuel consumption since tripmeter A was reset. When " ---.- " is displayed, see your dealer for service.

► **To reset the average fuel mileage and fuel consumption:**  **P.22**