


Bulb Lid



Removal

Remove the clips and the bulb lid.


Installation

Install the bulb lid and the clips.

Clip

Removal

1. Press down on the center pin to release the lock.
2. Pull the clip out of the hole.



Installation

1. Push the bottom of the center pin.



2. Insert the clip into the hole.
3. Press down on the center pin to lock the clip.