

Environment	116
Equipment	
Owner's Manual	39, 110
Tool Kit	39
F	
Flooded Engine	35
Front Suspension	87
Fuel	
Consumption Meter	20
Gauge	19
Mileage Meter	20
Recommended	37
Remaining	19, 20
Tank Capacity	37
Fuses	51, 106
G	
Gasohol	123
Gasoline	37
H	
Hazard Switch	32
Headlight Aim	85

Headlight Dimmer Switch	32
Helmet Holder	38
High Beam Indicator	31
High Coolant Temperature Indicator ...	30, 92
Honda Contacts	127
Horn Button	32

I

Ignition Cut-off System

Banking Sensor	110
Side Stand	75
Ignition Key	109
Ignition Switch	33, 35, 110
Indicators	30
Information Record	133
Instruments	18

L

Labels	7
Load Limits	15
Loading Guidelines	15
Low Oil Pressure Indicator	30, 93