


**Clock (12-hour display)  
To set the clock:  P.26**

**Odometer [TOTAL] & Tripmeter  
[TRIP A/B] & Stopwatch  P.18**

**Coolant temperature gauge (E)**  
When the coolant is over specified temperature, the segment H flashes.

**If the segment H flashes while riding:  P.99**

**Current fuel mileage, Average fuel mileage [AVG],  
Fuel consumption, and Average speed [AVG]  P.22**



**Speedometer**

**Fuel gauge**

Remaining fuel when only 1st (E) segment starts flashing: approximately 1.9 L (0.50 US gal, 0.42 Imp gal)

**If the fuel gauge indicator flashes in a repeat pattern or turns off:  P.102**

