


To Switch the multi-information display


To select the display area, repeatedly press the **MODE** button.

- u Can not select the INFO 3 display while pop-up information displayed. **➡P.90**


If the **MODE** button is not pressed within 10 seconds, the display returns to the riding mode display.



Riding mode **➡P.101**




INFO 1 display **➡P.28**



INFO 2 display **➡P.31**



INFO 3 display **➡P.39**



Press the **MODE** button